



C1 - Kompressor/compressor
 F1/FM - Kondensatorlüfter/condenser fan
 F2/FM - Verdampferlüfter/evaporator fan
 P1 - Anschlussstecker/power plug
 QF1 - Überlastungsschutz/over load protector

R1 - Relais/relay
 S1 - Hauptschalter/main
 S2 - Türkontaktschalter/door switch
 SQ1 - Temperaturfühler/temperature probe
 TH1 - Thermostat/thermostat